

Omega 550,551,552,560,561,562,563,564,565 Movement Parts (2)

Compiled by EmmyWatch - https://www.emmywatch.com

I have been in contact with Swatch to clear up why the bush needs to be reamed out. Swatch state that

"The bushings are made to tolerance and the fitting process requires it to be a tight fit in the rotor to insure it does not fall off in use.

This compresses the sides of the bush and therefore makes it a tight fit on the post.

Wear and manufacturing tolerances on the post require the bush to be made on the small side to allow for adjustment.

It would appear that a complete rotor with post also require reaming to fit.

Years ago rotor posts were manufactured in step sizes:-

72205501400(x) where x = B, C, D etc this allowed the selection of a post to fit the bush. But no more!

Although there are a lot of these watches out there, they have been out of production for a long time.

The re-manufacture of parts would have been done in large quantity batches and would preclude the possibility of matching individual parts."

I hope this clears up any questions or doubts regarding the bush supplied

