




Citizen 9270 Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>

Catalog No. 927-1



927-1
(Catalog No.)

927-1
(Catalog No.)

9270A, B, C, D, E


- Quartz crystal oscillator type LC digital display
- Constant display of hour, minute, second, and calendar
- 12-24 hour switching function
- Power cell life indicator

Thickness: 4.22mmt

EMMY WATCH
VINTAGE RESTORATIONS

Part No.	Part Name	9270A	9270B	9270C	9270D	9270E
101	Back case	101	101	101	101	101
102	Front case for LC display panel supporter	102	102	102	102	102
103	Back plate	103	103	103	103	103
104	LC display panel supporter	104	104	104	104	104
105	Power cell connector plate	105	105	105	105	105
106	Power case	106	106	106	106	106
107	LC display panel connection supporter	107	107	107	107	107
108	Power cell	108	108	108	108	108
109	LC display panel	109	109	109	109	109
110	Power complete	110	110	110	110	110

Size	25.8 x 23.2mm
Vibrations per second	32,768Hz



The power cell strap for checking is used when the checking is given to the single unit of the movement, and thus must be removed when the movement is set into the case.

Parts No.	Name of parts	Caliber No.																	
		9270A	9270B	9270C	9270D	9270E													
107	Stud pin	257	—	—	—	—													
186	Cover for LC display panel supporter	14	—	—	—	—													
211	Reflecting plate	88	89	—	—	—													
226	LC display panel supporter	109	—	—	—	—													
231	Power cell connector spring	80	—	—	—	—													
247	Device cover	197	216	285	286	287													
268	LC display panel connection rubber	57	—	—	—	—													
280	Power cell	46	—	—	—	—													
281	LC display panel	345	—	595	596	597													
750	Plate complete	742	—	—	—	—													
761	Power cell strap for checking	017	—	—	—	—													