




Citizen D130,D131,D132 Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>

Catalog No. D13-1
D15-1



D13-1
D15-1
(Catalog No.)

D130 • D313 • D132

- Digital quartz watch with shock sensor
- Time
- Calendar
- Alarm I/II
- Timer
- Stop watch with start timer, stop watch memo and stop watch counter
- Alarm monitor
- Lamp
(D130: Bicycle/D131: Ski/
D132: Jogging)

Thickness: 5.4mm^t

D150

- Digital quartz watch with shock & pace sensor
- Time
- Calendar
- Alarm
- Timer
- Stop watch with
 - Running pace detection split time memo
 - Running distance measurement
- Stop watch counter
- Alarm monitor
- Lamp


Thickness: 6.0mm^t

Size

28.4 x 26.3mm (D13*)
28.4 x 27.5mm (D15*)

Oscillation per second

32,768Hz



28.4 x 26.8mm (D13)	Size
28.4 x 27.5mm (D15)	
32,768Hz	Oscillation per second

