




## Kasper 1400,1401 Movement Parts (1)

*Compiled by EmmyWatch - <https://www.emmywatch.com>*



## Kasper 1400

10<sup>1</sup>/<sub>2</sub>''' SCD.

U 2941    W 2948    Zf 591



## Kasper 1401

10<sup>1</sup>/<sub>2</sub>''' SCD. CLD.

U 2941    W 2948    Zf 591