





Kasper 1450,1451,1452 Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>



Kasper 1450

11 1/2" SCD.

U 2941 W 2948 Zf Orig.



1150



1480



1482/1



1491





1496



1499



1500



Kasper 1451

11 1/2" SCD. CLD. (QG)

U 2941 W 2948 Zf Orig.



2542



2556





2575



2576

Automat.-Teile siehe Cal. 1450 (oben)



Kasper 1452

11 1/2" SCD. CLD. (QG)

U 2941 W 2948 Zf Orig.



1150



1480



1482/1



1491




1496



1499



1500



1134