



**EMMYWATCH**  
VINTAGE RESTORATIONS

**Rolex 1570 Movement Parts (1)**

*Compiled by EmmyWatch - <https://www.emmywatch.com>*

# Calibre 1570

Ø28.50mm  
Ht: 5.75mm  
Train: 19.800

- Automatic
- Centre Seconds
- Shock Proof
- 26 Jewels

Base Calibre 1530


















Image	Rolex No.	Description
	7978	Screw for stud holder
	7981	Screw for regulating the balance
	8050	Second wheel
	8051	Escape wheel, 26 jewels
	8065	Shock-absorber for balance-upper
	8074	Screw for balance stop spring
	8076	Bush for center wheel-lower
	8102	Balance bridge
	8103	Stud support with small plate

Image	Rolex No.	Description
	8106	Balance with Breguet hairspring, timed
	8108	Screw for balance
	8109	Automatic device upper bridge
	8110	Automatic device module
	8111	Set of screws
	8115	Balance stop spring
	8130	Main plate
	55051	Screw for stud