



Rolex 1575 Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>

Calibre 1575

Ø28.50mm
Ht: 6.30mm
Train: 19.800

- Automatic
- Calendar
- Centre Seconds
- Shock Proof
- 26 Jewels

Base Calibre 1530

Image	Rolex No.	Description
 	5093	Calendar wheel nut
 	7950	Centre wheel with cannon pinion
	7951	Cannon pinion ht. 2.75mm
 	7952	Hour wheel with double tothing
	7955	Date jumper
	7956	Date indicator seating, ref 1500, 1501, 1503
	7957	Screw for date jumper

Image	Rolex No.	Description
	7958	Stud for date indicator seating
	7959	Jewel for stud
	7960	Screw for date indicator seating
		Date indicator:
	7961-1	champagne
	7961-2	silvered
		Date indicator:
	7961-101	champagne, arabic
	7961-201	silvered, arabic
	7963	Date indicator seating, Ø ext. 27.86mm ref. 1600, 1601, 1602, 1603, 1605
	7964	Date indicator seating, Ø ext. 27.20mm ref. 1625

Image	Rolex No.	Description
	7978	Screw for stud holder
	7981	Screw for regulating the balance
	8006	Yoke for cam
	8007	Jewel for yoke for cam
	8008	Spring for cam yoke
	8011	Stud for cam
 	8021	Date wheel, mounted
 	8050	Second wheel
 	8051	Escape wheel, 26 jewels
	8065	Shock-absorber for balance-upper
	8074	Screw for balance stop spring
	8076	Bush for center wheel-lower
	8102	Balance bridge




Image	Rolex No.	Description
	8103	Stud support with small plate
	8106	Balance with Breguet hairspring, timed
	8108	Screw for balance
	8109	Automatic device upper bridge
 EMMYWATCH VINTAGE RESTORATIONS	8110	Automatic device module
	8112	Set of screws
	8115	Balance stop spring
	8119	Main plate

Image	Rolex No.	Description
	8131	Date indicator seating, Ø 29.46mm ref. 1530, 1630
7	55051	Screw for stud
	95098	Roller for date indicator seating
EMMYWATCH VINTAGE RESTORATIONS		