



Rolex 1580 Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>

Calibre 1580

Ø28.50mm
Ht: 5.75mm
Train: 19.800

- Automatic
- Anti-Magnetic
- Centre Seconds
- Shock Proof
- 26 Jewels

Base Calibre 1530










Image	Rolex No.	Description
	126	Bridle
	166	Screw for bridle
 	7950	Centre wheel with cannon pinion
	7951	Cannon pinion ht. 2.75mm
	7978	Screw for stud holder
	7981	Screw for regulating the balance
 	8050	Second wheel
  	8051	Escape wheel, 26 jewels
	8065	Shock-absorber for balance-upper
	8074	Screw for balance stop spring
	8076	Bush for center wheel-lower
	8102	Balance bridge

Image	Rolex No.	Description
	8103	Stud support with small plate
	8108	Screw for balance
	8115	Balance stop spring
	8120	Hour wheel ht. 1.80mm
	8121	Pallet fork
	8122	Balance with Breguet hairspring, timed
	8123	Automatic device upper bridge
	8124	Automatic device module
	8125	Anti-magnetic cover - protective case

Image	Rolex No.	Description
	8126	Anti-magnetic back - protective case
	8127	Back spring
	8128	Set of screws
	8129	Roller anti-magnetic
	8130	Main plate
	55051	Screw for stud