




Slava 2414 Movement Parts (1)

Compiled by EmmyWatch - <https://www.emmywatch.com>

СЛАВА SLAVA



Центральная секундная стрелка, противоударное устройство, анкерный ход, 21 рубиновый камень, календарное устройство, период колебания баланса 0,4 с.

Sweep second, shockproof device, lever escapement, 21 rubies, calendar, swing period 0,4 s.



Zentrumsekunde, Stoßsicherung, Ankerhemmung, 21 Rubinsteine, Kalendervorrichtung, Schwingungsdauer der Unruh 0,4 Sek.

Aiguille de seconde au centre, dispositif antichoc, échappement à ancre, 21 rubis, calendrier, période d'oscillation: 0,4 s.

Segundero central, dispositivo amortiguador, escape de áncora, 21 rubies, calendario, período de oscilación 0,4 s.






2414

КАЛИБР
CALIBRE
KALIBER
CALIBRE
CALIBRE



Калибр • Calibre • Kaliber • Calibre • Calibre
Ø 24 мм (mm), H=3,8 мм (mm)

2414



EMMY WATCH

VINTAGE RESTORATIONS

STAY
CALIBRE

2585/1
5110 5111 5125
4H-116M-18

7434
8336
52566 51147
2576
495 498
710 714
462 462
2566
7434

7147
5738 5750
5445
5425
5420
5415
5380

738 736 738
733 733
730 730
728 728

425 430 435 440 443 445
450 452
307 301
125

195 200/1 203 220 228
180/1 740
325 407 410 415 420 422/5 423
324 325 407 410 415 420 422/5 423
307 301 125
111 110 105 242 250 260 276 285 290 295 300 305 310 315 320 325 330 335 340 345 350 355 360 365 370 375 380 385 390 395 400 405 410 415 420 425 430 435 440 445 450 455 460 465 470 475 480 485 490 495 500 505 510 515 520 525 530 535 540 545 550 555 560 565 570 575 580 585 590 595 600 605 610 615 620 625 630 635 640 645 650 655 660 665 670 675 680 685 690 695 700